



QUALITY... PLAIN & SIMPLE®

Small Block Chevy Straight-Into-Block Engine Dipstick Installation Instructions

**Building American Quality...
With A Lifetime Warranty!®**

TOLL FREE 1-877-469-7440 • tech@lokar.com • www.lokar.com

General Installation Notes:

Please read these instructions completely before beginning the installation. If you have any questions please call.

Before beginning the installation, disconnect the negative battery cable and use wheel chocks to block the vehicle's wheels.

WARNING: Verify that the factory GM lower dipstick tube (GM part # 3951600) is installed in the engine block before using the Lokar Dipstick. If the lower dipstick tube is missing, the engine or Dipstick could become damaged when the engine is started.

Step 1: Remove the existing dipstick from the engine.

Step 2: Clean the area around the upper dipstick tube thoroughly, and remove the upper dipstick tube from the engine block.

Step 3: Lubricate the o-rings on the handle of the new Dipstick with clean engine oil, and insert the new Dipstick into the engine block.

